



USER'S MANUAL

Contents

Getting started	4
Getting to know the OmniHead	6
Setting up the OmniHead	7
Balancing the OmniHead	8
Using the OmniHead with DitoGear™ DragonBrdge	9
Conservation guidelines	9
Technical specifications	10
Obtaining Support	11
Limited Warranty	12
Miscellaneous	15

1. Getting started

Thank You very much for purchasing DitoGear™ motion control equipment. We hope that the devices will meet your expectations bringing a great value to your productions.

This manual includes hardware instructions for using the OmniHead. Depending on the bundle you purchased and the configuration of you setup, the head may be controlled by different controllers, such as:

1. Two DitoGear™ OmniControllers
2. A multi-axis real time joystick controller
3. DitoGear™ DragonBridge Interface
4. DitoGear™ Evolution software package and multi-axis motion control interface

Detailed instructions related to these devices has been delivered to you electronically with purchase of the device. In case you can't find them, download all manuals from:

www.ditogear.com/user-manuals

Please follow the instructions in this manual to learn how to get the most of the DitoGear™ OmniHead and DitoGear™ motion control devices.

Please ensure to carefully read the safety instructions and precautions contained in this manual and corresponding controllers manuals prior to the first use of the device.

Should you need any assistance or support do not hesitate to contact us at support@ditogear.com.

Product version information

This manual refers to DitoGear™ OmniHead V1 hardware version dated March 2012.

Latest product manuals can always be found at: www.ditogear.com/user-manuals

Precautions for safe use and optimal OmniHead performance

Please read and follow the guidelines below to use the OmniHead safely and ensure its best performance.

Caution!
INCAUTIOUS USE OF THE DEVICE MAY CAUSE SERIOUS INJURIES TO YOUR BODY. NEVER PUT YOUR HANDS OR FINGERS NEAR THE HEAD BODY, OR THE L-BRACKET DURING OPERATION!

Caution!
DitoGear is not responsible for any damage to the OmniHead, camera or other equipment caused by improper use of the device.

Caution!
Make sure not to put excessive load to the OmniHead. The payload that is considered as safe for optimal performance is 6kg (13lbs). You may use the head with payloads up to 10kg (22lbs) provided that the head is balanced properly. Never use the OmniHead under higher payloads - the device may get damaged and you may void the warranty.

Motor warning signals and behaviors.

The DitoGear™ OmniSlider Servo, OmniHead and LensDrive are equipped with an internal low-level servo motor controller protecting the motor from damage in result of overload or physical blockage of the moving parts.

When the axis motor approaches the performance limit you will hear a short repeating beep from the motor box. It indicates that the motor is working under high payload and is close to its performance limit.

When an excessive load is put on the axis motor or the device is not properly calibrated and the motor tries to work against physical limit, the motor controller will prevent the damage to the motor by cutting the power off. You will hear the continuous beep sound coming from the motor box. It indicates the motor stall.

In this situation you need to press the reset button on the motor housing (OmniSlider, LensDrive) or reconnect signal cable (OmniHead) and probably re-calibrate the device.

Taking the above into account, calibrate the device carefully.

2. Getting to know the OmniHead


The DitoGear™ OmniHead is a precise motorized pan and tilt head based on precise and power-efficient, digitally-controlled servo motors and has been designed for timelapse, stop motion animation and real time operation with DSLR, video and compact digital cinema cameras.

The OmniHead is a precisely machined unit consisting of highest quality hardware and electronics housed in a sealed enclosure. It is weather resistant meaning that it may work under standard conditions including light rain or light snow and low temperatures. However, it is not fully water resistant and should not be used under extreme conditions.

The OmniHead is capable of unlimited rotation in each of axes which may be only limited by the type of controller used.

The OmniHead consists of the following elements:

- 1 main body
- 2 mounting plate
- 3 external tilt axis traction system
- 4 traction belt tension adjustment system
- 5 RJ type signal & power cable connector
- 6 adjustable L-bracket support



3. Setting up the OmniHead

Follow the instructions below to setup the device for basic operation.

Using the device for the first time

- 1 Unpack the OmniHead and remove protective caps and bubble wraps. Be careful not to use any sharp device in order not to scratch the surface of the equipment.
- 2 Check the package contents with the equipment list included in the package or with the website.
- 3 Mount the OmniHead on the OmniSlider, tripod or other device you're planning on using.
- 4 Mount the camera on the L-bracket using appropriate screws, quick release mount or any other grip equipment of your choice.
- 5 Optionally, connect the rods adapter plate, rods system and DitoGear™ LensDrive to the kit.
- 6 To ensure optimal performance proceed with balance procedure as described in section 4 of this manual.
- 7 Connect the controllers system according to appropriate manuals and connect them to DitoGear™ OmniHead integrated signal and power cable. Finally connect the signal cable to the OmniHead with an RJ type plug.
- 8 If you're planning on using shutter release cable to trigger the DSLR camera shutter, connect it to the integrated signal and power cable and to your camera. There are 2 ports, each of them is controlled by separate controller. You may use any of them.
- 9 Put the head in the home position by slowly moving the L-bracket and the OmniHead body in pan and tilt axes. The pan home position is arbitrary. For the tilt home position it is assumed that the L-bracket is placed in the lowest position. When the system is not connected to any power source, it is possible to move the head manually in both axes with some resistance. Make sure to do it carefully and slowly.
- 10 Connect the power source to the integrated power and signal cable.
- 11 Proceed with calibration procedures as described in controllers systems manuals. After calibration the OmniHead is ready to work.

4. Balancing the OmniHead

To ensure optimal performance the OmniHead should be properly balanced, especially while working with higher payloads.

The balancing guidelines below assume that:

- 1 the OmniHead is already mounted to another device or a tripod
- 2 camera and all accessories are mounted to the L-bracket
- 3 the device is not connected to the power source

Follow steps below to balance the payload:

- 1 Unscrew partially the right clutch bolt so that it allows for the clutch block moves
- 2 Unscrew partially the left clutch bolt so that the clutch could move freely
- 3 Loosen the traction belt and remove it from the top gear completely. Be sure to hold your camera so that it does not fall.

- 4 At this point the L-bracket should move freely. Adjust the camera and equipment placement on the bracket so that it is more less balanced in tilt axis.
- 5 Try to keep the optical axis aligned horizontally to the OmniHead pan axis to avoid parallax effect while turning the head around. You may also want to try to keep the nodal point of the optical axis of your imaging system as close to pan axis as possible. Although not always, for some application it may be critical for achieving precise results.
- 6 As soon as the camera is balanced put the belt again on the gears and tighten it using the clutch.
- 7 Fix the clutch with the left bolt and then the right bolt.



5. Using the OmniHead with DitoGear™ DragonBridge

Use the following values in the configuration of the Dragonframe controlled device for each of axes to ensure proper operation.

- | | | |
|---|-----------------------|---------|
| 1 | Impulses per degree: | 485 |
| 2 | Steps per second max: | 100 000 |
| 3 | Backlash | 0 |

Steps per second and backlash may be overridden by the values of your choice if needed.

6. Conservation guidelines

1. While not in use OmniHead should be stored in a dry and dust-free place, preferably the Aluminum Transport Case from DitoGear™.
2. After use in humid or wet conditions make sure to clean the head with a soft fabric.
3. Never use any rust removers such as WD40 or similar products - they may solve the grease and cause damage to bearings.
4. You may grease the top bearing with a spray grease from time to time.

7. Technical specifications

Technical specifications table

Dimensions	350mm x 215mm x 75.5mm (13.7" x 8.4" x 3")
Weight	2750g (6 lbs)
Payload	6kg (13lbs) to 10kg (22lbs)*
Maximum camera half-width (as measured from the camera mounting plate holes to the farthest side of the body) or the L-bracket with from the farthest mounting hole to the vertical arm.	115mm
Maximum camera half-width (as measured from the middle mounting point to the farthest back element of the camera) to allow for continuous tilt rotation	165mm
Angular positioning precision	0.0225°
Max real time operation speed	45°/s (360°/8s)
Current draw	0.4A - 1A @ 12V
Power supply	10.5V - 14.4V DC
Operating temperature	-25°C to 50°C
Operating humidity	20% to 80%

* recommended max payload is 6kg (13lbs), however, if balanced properly, may work with payloads up to 10kg (22lbs).

The kit contents

The DitoGear™ OmniHead comes in a range of bundles and configurations. Check the following website to check the kit contents:

ditogear.com/products/omnihead/bundles/

Using 3rd party power adapters

DitoGear recommends using original DitoGear™ OmniPower AC/DC power adapter. If using a 3rd party adapter make sure it meets the requirements detailed in technical specifications table.

Caution! DitoGear is not responsible for any damage or failures caused by the use of a 3rd party power supply adapter.

8. Obtaining Support

In case of any technical issues that can't be solved by reading the manuals carefully do not hesitate to contact DitoGear support at support@ditogear.com

9. Limited Warranty

DitoGear One (1) Year Limited Warranty
For DitoGear Products Only

Consumer rights and restrictions.

For consumers, who are covered by consumer protection laws or regulations in their country of purchase or, if different, their country of residence, the benefits conferred by this warranty are in addition to all rights and remedies conveyed by such consumer protection laws and regulations. This warranty does not exclude, limit or suspend any rights of consumers arising out of non-conformity with a sales contract. However, as described below, DitoGear disclaims statutory and implied warranties to the extent permitted by law, and in so far as such warranties cannot be disclaimed, all such warranties shall to the extent permitted by law be limited in duration to the duration of the express warranty described below and to the repair or replacement service as determined by DitoGear in its sole discretion. Some states (countries and provinces) do not allow limitations on how long an implied warranty or condition may last, so the limitations described above may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state (or by country or province). This limited warranty is governed by and construed under the laws of the country in which the product purchase took place. DitoGear, the warrantor, under this limited warranty stands for Dito Productions, Maria Paluch, ul.Krańcowa 30, 62-002 Suchy Las, Poland.

Warranty.

DitoGear's warranty obligations for this hardware product are limited to the terms set forth herein. DitoGear warrants this DitoGear-branded hardware product against defects in materials and workmanship under normal use for a period of one (1) year from the date of retail purchase by the original end-user purchaser ("Warranty Period"). If a hardware defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, DitoGear will either (1) repair the hardware defect at no charge, using new or refurbished parts that are equivalent to new in performance and reliability, (2) exchange the product with a product that is new or refurbished that is equivalent to new in performance and reliability and is at least functionally equivalent to the original product, or (3) refund the purchase price of the product. DitoGear may request that you replace defective parts with user-installable new or refurbished parts that DitoGear provides in fulfillment of its warranty obligation. A replacement product or part, including a user-installable part that has been installed in accordance with instructions provided by DitoGear, assumes the remaining warranty of the original product or ninety (90) days from the date

of replacement or repair, whichever provides longer coverage for you.

When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes DitoGear's property. Parts provided by DitoGear in fulfillment of its warranty obligation must be used in products for which warranty service is claimed. When a refund is given, the product for which the refund is provided must be returned to DitoGear and becomes DitoGear's property.

Exclusions and limitations.

To the extent permitted by law, this warranty and the remedies set forth above are exclusive and in lieu of all other warranties, remedies and conditions, whether oral, written, statutory, express or implied. As permitted by applicable law, DitoGear specifically disclaims any and all statutory or implied warranties, including, without limitation, warranties of merchantability and fitness for a particular purpose and warranties against hidden or latent defects. If DitoGear cannot lawfully disclaim statutory or implied warranties then to the extent permitted by law, all such warranties shall be limited in duration to the duration of the express warranty and to the repair or replacement service as determined by DitoGear in its sole discretion. Some states (countries and provinces) do not allow limitations on how long an implied warranty or condition may last, so the limitations described above may not apply to you. No DitoGear reseller, agent, or employee is authorized to make any modification, extension, or addition to this warranty. If any term is held to be illegal or unenforceable, the legality or enforceability of the remaining terms shall not be affected or impaired.

This Limited Warranty applies only to hardware products manufactured by or for DitoGear. The Limited Warranty does not apply to any non-DitoGear hardware products even if packaged or sold with DitoGear hardware. Manufacturers or suppliers, other than DitoGear, may provide their own warranties to the end user purchaser, but DitoGear, in so far as permitted by law, provides their products "as is".

DitoGear does not warrant that the operation of the product will be uninterrupted or error-free. DitoGear is not responsible for damage arising from failure to follow instructions relating to the product's use.

This warranty does not apply: (a) to consumable parts, such as batteries, unless damage has occurred due to a defect in materials or workmanship; (b) to cosmetic damage, including but not limited to scratches, dents and broken elements on ports; (c) to damage caused by use with non-DitoGear products; (d) to damage caused by accident, abuse, misuse, liquid contact, fire, earthquake or other external causes; (e) to

damage caused by operating the product outside the permitted or intended uses described by DitoGear; (f) to damage caused by service (including upgrades and expansions) performed by anyone who is not a representative of DitoGear; (g) to a product or part that has been modified to alter functionality or capability without the written permission of DitoGear; (h) to defects caused by normal wear and tear or otherwise due to the normal aging of the product.

Except as provided in this warranty and to the extent permitted by law, DitoGear is not responsible for direct, special, incidental or consequential damages resulting from any breach of warranty or condition, or under any other legal theory, including but not limited to loss of use; loss of revenue; loss of actual or anticipated profits (including loss of profits on contracts); loss of the use of money; loss of anticipated savings; loss of business; loss of Opportunity; loss of goodwill; loss of reputation; loss of, damage to or any indirect or consequential loss or damage howsoever caused including the replacement of equipment and property. The foregoing limitation shall not apply to death or personal injury claims, or any statutory liability for intentional and gross negligent acts and/or omissions. Some states (countries and provinces) do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

Obtaining warranty service.

DitoGear will provide warranty service either (i) at an DitoGear Retail or DitoGear Authorized Service Provider (“ASP”) location, where service is performed at the location, or the DitoGear Retail or ASP may send the product to an DitoGear repair service location for service, (ii) by sending you prepaid way bills (and if you no longer have the original packaging, DitoGear may send you packaging material) to enable you to ship the product to DitoGear’s repair service location for service, or (iii) by sending you customer installable new or refurbished replacement product or parts to enable you to service or exchange your own product (“DIY Service”). Upon receipt of the replacement product or part, the original product or part becomes the property of DitoGear and you agree to follow instructions, including, if required, arranging the return of original product or part to DitoGear in a timely manner. When providing DIY Service requiring the return of the original product or part, DitoGear may require a credit card authorization as security for the retail price of the replacement product or part and applicable shipping costs. If you follow instructions, DitoGear will cancel the credit card authorization, so you will not be charged for the product or part and shipping costs. If you fail to return the replaced product or part as instructed or the replaced product or part is not eligible for warranty service, DitoGear will charge the credit card for the authorized amount.

Please access and review the online help resources at the DitoGear website (www.ditogear.com) and contained in the product manual before requesting warranty service. If the product is still not functioning properly after making use of these resources, please contact DitoGear at support@ditogear.com.

Service options, parts availability and response times may vary according to the country in which service is requested. Service options are subject to change at any time. You may be responsible for shipping and handling charges if the product cannot be serviced in the country in which service is requested. If you seek service in a country that is not the country of purchase, you will comply with all applicable import and export laws and regulations and be responsible for all custom duties, VAT, and other associated taxes and charges. For international service, DitoGear may repair or exchange defective products and parts with comparable products and parts that comply with local standards. In accordance with applicable law, DitoGear may require that you furnish proof of purchase details before receiving warranty service.

Privacy.

DitoGear will maintain and use customer information in accordance with the DitoGear Customer Privacy Policy available at www.ditogear.com/legal/privacy-policy/.

10. Miscellaneous

Trademarks and copyrights

DitoGear™, DitoGear™ OmniController, DitoGear™ OmniSlider, DitoGear™ OmniHead and DitoGear™ LensDrive are trademarks of Dito Productions Maria Paluch ul.Krańcowa 30, 62-002 Suchy Las, Poland. Unauthorised use is strictly prohibited. All other trademarks referenced in this manual are used only for informative purposes and are property of their respective owners.

Disposal and recycling information

The device and all batteries included with it must be disposed of properly according to local laws and regulations. The product must be disposed of separately from the household waste. When your product reaches its end of life, contact DitoGear or your local authorities to learn about recycling options.



WWW.DITOGEAR.COM